ICY BOX
http://www.icybox.de

IB-390 Series
External Case for 3.5" HDD

IB-390StUS-B
External Case incl. stand foot

IB-390StUSD-B
External Case incl. 5.25" docking station

Features

- For 3.5" SATA HDD
- Full aluminium enclosure
- Combo host USB2.0 + eSATA
- Screw less HDD Installation-Mechanism
- **IB-390StUSD-B:** incl. 5.25" docking station for PC Case
- **IB-390StUS-B:** incl. stand foot
- Data transfer up to 3 Gbit/s (eSATA)
- Supports: Windows 98/ME/2000/XP/Vista, OS 9.1
- Hot Swappable

Technical Data

Model	IB-390StUS-B	IB-390StUSD-B
Articel No.	22390	22391
EAN code	4250078183754	4250078183761
Case colore	black	black
Docking station	-	yes (SATA)
Brand	ICY BOX	
Drive interface	1x 3.5" SATA	
Host inteface	1x USB2.0, 1x eSATA	
HDD capacity	No Limit	
Case material	Aluminium	
Hot-Swappable	yes	
Packing content	1x Case,	1x Case,
	1x stand foot,	1x Docking station,
	1x power adapter + cord,	1x power adapter + cord,
	1x eSATA cable,	1x eSATA cable,
	1x USB cable,	1x USB cable,
	1x key,	1x key,
	1x manual	1x srew set,
		1x manual

IB-390StUS-B and IB-390StUSD-B! ICY BOX complements its portfolio around a further product combination for 3.5" SATA HDDs.

With the new IB-390 series ICY BOX continues its concept of the combined internal/externally solutions.

The IB-390 is available with docking station (IB-390StUSD-B) or without (IB-390StUS-B). The fan less aluminium carrier provides an optimal working environment to the most 3.5" SATA HDDs.

The HDD enclosure can be inserted in the stationary PC by using the docking station, but also be connected via USB 2.0 or eSATA interface directly. Therefore, the enclosure finds a comfortable place inside the computer and can also be used away from home without a docking station.

ICY BOX IB-351B-BL   ICY BOX IB-550   ICY BOX IB-360B

Frontside

Rearside

Screw less HDD Installation-Mechanism

1. For unblock the external enclosure using the key including the packing content. You are able to open the locking mechanism from the centre of rear panel by unsnap the clamp retention.
2. Take out the PCB frame, fix a 3.5" SATA HDD to the metal frame and connect it to the internal SATA and power connections.
3. Push the unit back into the enclosure and close the clamp retention.
4. **IB-390StUSD-B:** Screw docking station into a 5.25" drive bay, connect the power cable of it to the power supply and the data cable to the controller.

Logistical Data: IB-390StUS-B

Packing unit:	10 pcs./carton	**Gross weight (incl. pack.):**	1.3 kg	**Country of origin:**	China
Total weight:	14.2 kg/carton	**Dimension (incl. pack.):**	280x175x110 mm	**Import tax:**	84733080
Dimension/carton:	580x390x310 mm	**Net weight:**	0.5 kg		
Dimension of articel:	191x124x33 mm				

Logistical Data: IB-390StUSD-B

Packing unit:	10 pcs./carton	**Gross weight (incl. pack.):**	1.6 kg	**Country of origin:**	China
Total weight:	17.2 kg/carton	**Dimension (incl. pack.):**	280x175x110 mm	**Import tax:**	84733080
Dimesion/carton:	580x390x310 mm	**Net weight:**	1.13 kg		
Dimension of articel:	205x145x42 mm				